

Rebar Bender - Electric - Instructions for Use

HireKING

SAFETY FIRST

If you are collecting the equipment for someone else, please make sure this sheet is given to the equipment user to read. This sheet should be given to the site supervisor if the equipment is being hired for commercial use so that the information is available to all users. Before starting any job, be sure to spend a few minutes planning and understanding the hazards and risks of the activity and determining how you will control them to prevent injury or damage.

Note: This safety and instruction sheet is on the main machine only, you will be issued with additional sheets for the attachments you have.

REQUIRED SAFETY EQUIPMENT



Set up

1. Place machine on flat level site
2. Plug into 240V power supply

Pre-Start Checks and Safety

- Ensure the tool has a current electrical tag
- Ensure work area is clear at all times
- Do not use in damp or wet locations
- Keep children and unnecessary people away from work area
- Store correctly when not in use
- Never force the tool, let it do the work
- Do not wear loose clothing and jewellery and use caution with long hair etc
- Secure work, use clamps etc if necessary
- Avoid unintentional starting and do not carry the tool around while plugged in
- If an extension cord is required ensure it is heavy duty and a maximum of 20 metres
- If required have your tool repaired by a qualified person
- Only use the tool for what it was intended for
- Never exceed the maximum capacities of the tool
- If the unit malfunctions during operation or you hear any abnormal noise, turn the machine off and have it checked by a qualified person
- Always ensure the cutter cover is closed when using the tool for bending, this prevents foreign objects jamming that can cause serious accidents
- The unit is not a handheld tool, it should only be used on stable ground etc

Stopping and After Use

1. Allow unit to cool down
2. Pack away tidy in carry case

When Operating

Cutting:

- Open the plastic cutter cover to expose the cutting mechanism
- Set the main control selector switch to the cut position
- Rotate the machine 90° so the cutting mechanism is at the top of the machine
- Set the rebar to be cut on the lower cutter
- Ensure both ends of the rebar protrude past the stoppers on either side of the machine
- Pull the switch and cut the rebar ensuring you keep your hands clear of moving parts

Bending:

- Close the plastic cutter cover to protect the cutting mechanism and operator's safety
- Place the machine flat on a hard-clear surface (as the rebar bends so will the ends of the length of rebar)
- Set the main control selector switch to the diameter of the rebar and the angle to be bent (use the angle marks merely as a rough guideline)
- Place the rebar to be bent on the centre plate and set it so that it is horizontal with the turntable surface
- Ensure both ends of the rebar protrude at least 200mm past the stoppers on either side of the machine
- Pull the switch and continue pulling until the motor makes reverse rotation and the bending roller starts to return ensuring you keep your hands clear of moving parts
- Do not bend more than 50 rebars in one session as this will overload the motor, and may cause it to burn out

CONTACT US

If you are having any difficulties with this piece of machinery/equipment, please contact us immediately on 0800 30 30 20 follow the options to General Hire.