





# Lighting Tower - Instructions for Use

HireKING

## SAFETY FIRST

If you are collecting the equipment for someone else, please make sure this sheet is given to the equipment user to read. This sheet should be given to the site supervisor if the equipment is being hired for commercial use so that the information is available to all users. Before starting any job, be sure to spend a few minutes planning and understanding the hazards and risks of the activity and determining how you will control them to prevent injury or damage.

<p><b>Note: This safety and instruction sheet is on the main machine only</b></p>	<p><b>RECOMMENDED SAFETY EQUIPMENT</b></p> <div> Foot Protection</div> <div> Hand Protection</div> <div> Hearing Protection</div>
	<p><b>Pre-Start Checks and Safety</b></p> <ol style="list-style-type: none"><li>1. Check fuel tank is full, and cap secures correctly</li><li>2. Check for loose nuts, bolts, or screws</li><li>3. Make sure the job site is safe to operate on</li><li>4. Check the unit has an electrical tag and is current</li><li>5. Check the trailer system is damage free and working</li><li>6. Check for overhead electrical lines</li></ol> <p><b>When Operating</b></p> <ol style="list-style-type: none"><li>1. Use appropriate PPE</li><li>2. Ensure all by standers are aware of the work proceedings</li><li>3. Ensure unit is disconnected from towing vehicle</li><li>4. Make sure the hand brake is put in the ON position</li><li>5. Do not move the unit while the mast is extended</li></ol>
<p><b>Starting Procedure</b></p> <ol style="list-style-type: none"><li>1. Level machine by setting stabiliser legs</li><li>2. Position the LED lights to the correct position for desired lighting area</li><li>3. Raise the mast to desired height</li><li>4. Select desired operation mode</li></ol>	<p><b>Stopping and After Use</b></p> <ol style="list-style-type: none"><li>1. Lower the mast all the way to the bottom and secure</li><li>2. Press the STOP button</li><li>3. Turn the operation dial to the OFF position</li><li>4. Turn OFF the battery isolator switches (if required for specific model)</li><li>5. If moving, ensure stabilisers are up and stowed</li></ol>
<p><b>CONTACT US</b></p> <p>If you are having any difficulties with this piece of machinery/equipment, please contact us immediately on 0800 30 30 20 follow the options to General Hire.</p>	